BALTOSCOPE FPDIGIT 22-100



www.balteau.com

BALTOSSCOPE FPDigit 22-100

HERE COLUMN TO DO TO DO	1000 be	10201 00100
		$\langle \langle \rangle$
00000		000000
om ballo ballo om balleau bal	on balle bal	om ball ball
atteau.com batteau.com b	u.com com b	
Decenter type: Amernhous cilicon		
Allorphous sincon	Amorphous silicor	Receptor type:
Conversion screen: DRZplus	100 - 101 Bar	28 DA
Same	DRZplus	Conversion screen:
Conversion screen: DRZplus	DRZplus 409,6 x 409,6 mm	Conversion screen: Pixel area:
Conversion screen: DRZplus Pixel area: 409,6 x 409,6 mm	DRZplus 409,6 x 409,6 mm 100 µm ³	Conversion screen: Pixel area: Pixel pitch:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²	DRZplus 409,6 x 409,6 mm 100 µm [;] 50 lp/cm	Conversion screen: Pixel area: Pixel pitch: Spatial resolution:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²Spatial resolution:50 lp/cm	DRZplus 409,6 x 409,6 mm 100 µm [;] 50 lp/cm > 84 dE	Conversion screen: Pixel area: Pixel pitch: Spatial resolution: Dynamic range:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²Spatial resolution:50 lp/cmDynamic range:> 84 dB	DRZplus 409,6 x 409,6 mm 100 µm 50 lp/cm > 84 dE 16 bits	Conversion screen: Pixel area: Pixel pitch: Spatial resolution: Dynamic range: AD/conversion:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²Spatial resolution:50 lp/cmDynamic range:> 84 dBAD/conversion:16 bits	DRZplus 409,6 x 409,6 mm 100 µm 50 lp/cm > 84 dE 16 bits 15 fp:	Conversion screen: Pixel area: Pixel pitch: Spatial resolution: Dynamic range: AD/conversion: Frame rate*:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²Spatial resolution:50 lp/cmDynamic range:> 84 dBAD/conversion:16 bitsFrame rate*:15 fps	DRZplus 409,6 x 409,6 mm 100 µm 50 lp/cm > 84 dB 16 bits 15 fps 160 kV	Conversion screen: Pixel area: Pixel pitch: Spatial resolution: Dynamic range: AD/conversion: Frame rate*: Standard shielding:
Conversion screen:DRZplusPixel area:409,6 x 409,6 mmPixel pitch:100 µm²Spatial resolution:50 lp/cmDynamic range:> 84 dBAD/conversion:16 bitsFrame rate*:15 fpsStandard shielding:160 kV	DRZplus 409,6 x 409,6 mm 100 µm 50 lp/cm > 84 dE 16 bits 15 fps 160 kV 215 W	Conversion screen: Pixel area: Pixel pitch: Spatial resolution: Dynamic range: AD/conversion: Frame rate*: Standard shielding: Power supply:

* @ 400x400 μm^2 (100x100 μm^2 -> 3,75 fps)

Flexibilty

Compared to classical Film radiography, the FPDigit provides: the choice in beam or view incidence to give the selected view of an indication in the product, enlargement capabilities and inspection cost reductions. This is giving a fast decision (compared to film) thanks to direct observation in the screen of the monitor of the FPDigit control unit.


The resolution

The resolution of a flat panel is a function of several factors. The pitch size will give the spatial resolution of the detector and must be selected taking into account Applications, X ray sources and Budgets. The smaller the pixel is, the higher resolution can be. But the same result can sometimes be obtained using Magnification if Geometry of exposure and X ray sources are correctly selected. The pitch size directly interferes on the Modulation Transfer Frequency (MTF) or the Spatial Frequency Response. The MTF defines the sharpness of a whole system for displaying fine details. This is then the final result in terms of definition for the said detector. MTF are expressed in pairs of lines. The driving electronic attached to the panel is another very important factor as it will collect and send the signal to the

The FPDigit 22-100 is high dynamic range x-ray detector. With its 16 inch, more than 16 millions pixels and 100 μm pixel pitch, this flat panel will offer a dynamic range over 84dB with a frame rates up to 15 frames per second. The acquisition of image will be made by optical data communication.

Improved reliability in inspections, costs reductions and environment cares are today the major factors driving the selection of Radiographic techniques. Due to the progression of silicon technologies and the level of current electronics, signals processing and transfer are becoming efficient and affordably priced to be used in NDT Industries.

Flat panels are a combination of electronic and Silicon technologies which gives a direct conversion media for displaying Radiographic Images instead of using films. Flat panels are basically a two dimension array of detectors which sensitivity is 10 to 100 times greater than conventional films. This helps in reducing exposure time but also gives an extended range of thicknesses with the same use of energy.



computer with more or less efficiency depending on the construction and quality. For instance, Shielding (intrinsically) of this section to the appropriate level of energy will guarantee that no noise or even worse, no damages, will happen to the module.

« Real » Real time

Fast conversion system where no latency is expected due to the working mode. Acquisition rates are as fast as a human eye can see and there are basically no integration time. However, if required, the user may freely select the integration parameters and get slower frame rates but increased X ray sensitivity.

Image enhancement


If you display a given size indication on a defined area and you increase the size of the displaying area, you will get an increased definition or precision when measuring the indication. That will help him emphasizing tiny details that are barely visible otherwise. This greatly helps interpretation works too and provides an excellent tool for Real time process monitoring.

BALTOSCOPE FPDIGIT 22-100

BALTOSCOPE FPDIGIT 22-100

Specifications	Units	BALTOSCOPE FPDigit 22-100
Dimensions:	ст	67,2 x 59,9 x 44
Weight:	kg	25
Housing:		Aluminium
Receptor Type:		Amorphous silicon
Conversion screen:		DRZplus (Csl available in the options)
Pixel matrix:	pitch	4096 x 4096 @ 100 μm pixel pitch
Spatial resolution	lp/cm	50
A/D Conversion:	bits	16
Amplifiers		Low noise ASICs with 6 user selectable gain settings
Dynamic range:	dB	> 84
Energy range (standard):	kVp	40 - 15000
Lag:		< 8% 1st frame
System Interface:		Fiber-optical
Operating temperature:	°C	10 / 35
Storing temperature:	°C	-10 / 50
Humidity:	%	30 - 70% RH (non condensing)
Supply:		100 - 240 VAC, 50 - 60 Hz (FPDigit22-200 Power supply 215 W)
Dissipation:		90 W

		Matrix	Pixel (µm²)	16 bits
Read-out-mode	Square	4096 x 4096	100 x 100	3,75 fps
Read-out-mode	Square	2048 x 2048	200 x 200	7,5 fps
Read-out-mode	Square	1024 x 1024	400 x 400	15 fps





OPTIONAL EQUIPMENT

- IPS012
- Csl scintillator

Contact details

Balteau NDT Rue Voie de Liège, 12 B-4681 Hermalle Sous Argenteau Belgium

www.**balteau**.com balteau@**balteau**.com Tel. +32 (0) 4 374 75 75 Fax +32 (0) 4 374 75 85

All specifications are non contractual and are subject to change without prior notice

Distributed by:

