BALTOGRAPH XSD225/4KW



BALTOGRAPH XSD225/4KW



The XSD225/4KW is probably the best compromise in power and size for applications. medium thickness Completely renewed during summer 2014, it keeps all previsous features but has been made with the lastest available components, reduced in size, weight and the most important, is more powerfull, offering 4000W. Able to be operated as down as 5 kV where you will use it for composite and light alloys applications, at full power, you will be able to get radiographies of medium walled steel castings with incomparable qualities.

The XSD225/4KW is a very powerful, stable and sturdy unit that can be used as a mobile unit or as a fixed one in any customized systems for production. A very large variety of tubeheads is available and the unit can then be easily turned into a Panoramic or a Directional X-ray equipment.

MAIN FEATURES

- High frequency constant potential generator
- « Ripple free »
- · High duty cycle
- Output power up to 4000W
- Current up to 30 mA
- Metal-ceramic tube
- · Stationary or mobile unit
- Full automatic preheating
- Very stable output
- Safety first, X-ray start with 2 buttons
- Low consumption






KEY ADVANTAGES

- Very reliable
- Powerful, steadiness & sturdinesss
- Solid insulation HV module : more convenient for the maintenance
- · No gas and no oil to isolate
- Can be turned into panoramic or directional x-ray equipment
- · Can drive up to two individual filament
- · Can be combined to a RS232 interface
- CANON military metallic connectors

MOST COMMON APPLICATIONS

- Oil & Gas
- Energy
- Aeronautical/aerospace
- Transport
- Military
- Bio-medical & agriculture
- And much more



Combined to our computerized control panel (LS1 series), it can be integrated in any environment, can replace the majority of existing units without big changes or any, or can be installed as a single end unit, stationary or mobile (XMD).

INTERNATIONAL

- CE certified
- NFC74-100 LCIE Certified

All specifications are non contractual and are subject to change without prior notice

BALTOGRAPH XSD225/4KW

| Specifications | Units |
|------------------------------|-------|
| High voltage range | kV |
| Tube current range | mА |
| Focal spot size (IEC336) | |
| Ripple | |
| Maximum output power | Watt |
| Frequency | Hz |
| Current | А |
| Steel penetration at max (*) | тт |
| Working temperature | °C |
| Anode cooling type | |
| Duty cycle | % |
| Insulation | |
| Voltage | V |
| Weight | Kg |
| Tubehead | |
| Control unit: | |

| XSD225/4KW |
|-------------------------|
| 5 - 225 |
| 0,1 - 30 |
| From 0,2 x 0,2 to 3 x 3 |
| 0,1% PP |
| 4000 |
| 47 - 63 |
| 18 |
| 54 |
| 0 to 45°C |
| Water |
| 100% |
| Encapsulated |
| 230 (-15% +10%) |
| 109 |
| Metal-Ceramic |
| LS1 |

* FFD= 700mm/Film Carestream Industrex AA400/D=2.0/t=10min.



LS1

| kV step: | 1 - 2 - 5 |
|------------|-----------------|
| mA step: | 0,1 - 0,2 - 0,5 |
| Memories: | 10.000 |
| Casing: | Aluminium |
| Frequency: | 45 - 66 Hz |
| Mains: | 90 - 245 V |
| Weight: | 4,8kg |

1 - 2 - 5

| A A A A A A A A A A A A A A A A A A A | | |
|---------------------------------------|-----|-------|
| 000 | LS1 | e nee |

LS1-C2 • kV step:

•

1 - 2 - 5 mA step: 0,1 - 0,2 - 0,5 10.000 • Memories: Aluminium • Casing: 45-66 Hz • Frequency: 90 - 245 V • Mains:

STANDARD EQUIPMENT

- X-Ray generator : XSD or CLD
- Tubehead : TSD or TSC
- Control unit : LS1 or LS1C
- A cable from the generator to the control panel
- A main power cable

OPTIONAL EQUIPMENT

- Warning flashing light with 20 m cable
- Closed circuit type water cooling unit
- · Water security box

Produced by:

Balteau NDT Rue Voie de Liège, 12 B-4681 Hermalle Sous Argenteau Belgium

www.balteau.com balteau@balteau.com Tel. +32 (0) 4 374 75 75 Fax +32 (0) 4 374 75 85

All specifications are non contractual and are subject to change without prior notice

Distributed by:

OGRAPH XSD225/4KW BALT(

1805